

PELLET LOSS PREVENTION

LOADING INSTRUCTIONS



FOR **BULK**
TRANSPORT




ANY QUESTIONS?
ASK ASSISTANCE



UNLOCK
MIN. 4 TANK LIDS



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK



SAMPLE TAKING?
ONLY ON SITE

PELLET LOSS PREVENTION

LOADING INSTRUCTIONS



FOR **BULK**
TRANSPORT



ANY QUESTIONS?
ASK ASSISTANCE



UNLOCK
MIN. 4 TANK LIDS



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK



SAMPLE TAKING?
ONLY ON SITE

PELLET LOSS

PREVENTION

LOADING INSTRUCTIONS




FOR **BULK**
TRANSPORT



ANY QUESTIONS?
ASK ASSISTANCE



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK



SAMPLE TAKING?
ONLY ON SITE

PELLET LOSS PREVENTION

LOADING INSTRUCTIONS



FOR **BULK**
TRANSPORT



ANY QUESTIONS?
ASK ASSISTANCE



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK




SAMPLE TAKING?
ONLY ON SITE

PELLET LOSS

PREVENTION

LOADING INSTRUCTIONS




FOR **PALLETIZED** TRANSPORT




ANY QUESTIONS?
ASK ASSISTANCE



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK



LASHING BELTS MAY
NOT DAMAGE GOODS!



SAMPLE TAKING?
ONLY ON SITE

PELLET LOSS

PREVENTION

LOADING INSTRUCTIONS




FOR **PALLETIZED** TRANSPORT




ANY QUESTIONS?
ASK ASSISTANCE



SPILLS?
DON'T LEAVE, REPORT



CLEAN
YOUR TRUCK




LASHING BELTS MAY
NOT DAMAGE GOODS!

PELLET LOSS PREVENTION


UNLOADING INSTRUCTIONS




BULK




COUPLE TO SILO
WHEN PERMITTED



ALWAYS USE 2
SILO HOSE CLAMPS



EMPTY?
BLOW OUT THE HOSE



REMOVE AND DISPOSE
LINER AT
DEDICATED AREA ON SITE


PELLET LOSS

PREVENTION


UNLOADING INSTRUCTIONS



FOR **PALLETIZED** TRANSPORT



CLEAN TRAILER
AFTER UNLOADING



CLEAN AREA,
USE WASTE BINS